RODEN LEATHER REUPHOLSTERY GUIDELINES

FABRIC TO LEATHER CONVERSION based on 54" fabric

LOVESEATS PAGE 1



52" Slipper Loveseat 9 yards = 162 sq ft



60" Tight Back Roll Arm Loveseat 10.5 yards = 189 sq ft



55" Curved Back Settee 8 yards = 144 sq ft



68" English Roll Arm Loveseat 11 yards = 198 sq ft



59" Chippendale Style Settee 9.5 yards = 171 sq ft



Danish Modern Loveseat 11 yards = 198 sq ft



68" Scroll Arm Settee 11 yards = 198 sq ft



66" Track Arm Loveseat 11 yards = 198 sq ft



60" Flared Arm Loveseat 10 yards = 180 sq ft



66" Roll Arm Loveseat 11 yards = 198 sq ft



62" Tufted Curved Back Loveseat 10 yards = 180 sq ft



51" French Victorian Settee 6 yards = 108 sq ft

https://www.rodenleather.com/leather-reupholstery-guide 1-800-521-4833

RODEN LEATHER REUPHOLSTERY GUIDELINES

FABRIC TO LEATHER CONVERSION based on 54" fabric

LOVESEATS PAGE 2



66" Loveseat Skirted 12 yards = 216 sq ft



60" Tight Back English Roll Arm 10 yards = 180 sq ft



63" Tight Back Roll Arm Loveseat 11 yards = 198 sq ft



68" Tufted Loveseat with Roll Arm 12 yards = 225 sq ft



51" Barcelona Style Loveseat 7 yards = 127 sq ft



62" Mid Century Modern Loveseat 7 yards = 126 sq ft



64" Pillow Top Arm Loveseat 11.5 yards = 207 sq ft



62" French Provincial Tufted Settee 10 yards = 180 sq ft



60" Track Arm French Loveseat 9 yards = 162 sq ft